


## Operating Instructions:

\* For best performance, return switch to the OFF position when the light will be not used for a prolonged period.

### Power On/Off and Changing Modes:

- Slide switch on top of light to select desired mode.
- When facing light, slide switch away 1 stop for low, and 2 stops for high.
- To turn the light off return the switch to its original position.
- The light will blink to indicate it is automatically turning off after approximately 5 hours.
- Return switch to Off position when not being used



### Runtimes:

Mode:	Low	High
Runtime:	40 hours	27 hours

### Charging:


- Plug supplied charger into wall outlet and connect to your light via the DC jack.
- **Only use the supplied charger** with this light. Using any device other than the one supplied will damage the light.
- Red LED on the charger indicates it's currently charging.
- Green LED or no LED indicates charger has completed its charge cycle.
- Light will charge in 4.5 hours or less.
- Unplugging the light from the charger will not harm it but for best performance please allow charger to complete its cycle (green LED displaying).
- Your Rechargeable Micro Series will blink and turn itself off when it needs to be charged. If light fails to run for 5 hours, connect to charger.
- For best performance, please charge your light before first use.



**SEE REVERSE SIDE FOR FURTHER INSTRUCTIONS  
AND PRODUCT PRECAUTIONS**

## Placing Rechargeable Micro Series on Artwork:

- This light is designed to rest on top of frames, artwork, and display cases.
- Simply place the light behind the artwork such that the flat, horizontal panel (Mounting Edge) rests atop the edge of your subject.
- If light has difficulty balancing on top of frame, attach the included adhesive backed rubber spacers. To apply, remove white paper lining and adhere to your light as shown. It is recommended you first degrease the area where they'll be applied by using a paper towel and rubbing alcohol.



## OPERATING WARNINGS:

- **AVOID EYE INJURY** - Do not stare directly into beam or shine it directly into anyone's face. Doing so could cause retinal damage.
- Do not operate this light while attached to the charger. Doing so could result in damage to your light. Unplug your light from the charger before use.
- Never connect the light to any item other than the supplied charger. Doing so may damage the product and void your warranty, and could possibly result in fire, electric shock or other bodily injury.
- Use in a dry and safe location. Our products are meant for indoor and dry locations only.
- Inspect your light carefully before use. Product can become damaged in shipping. Contact us if you have any of the following signs of a defective product: cuts or damage to electrical cord, damage to light head, or signs of damage on any part of the product.

## PRECAUTIONS:

- To avoid risk of damage to eyesight, never look directly into the beam when the light is on, nor shine it directly into another person's eyes.
- Any battery may rupture or explode if put in a fire or otherwise exposed to excessive heat. To avoid risk of injury, do not expose this light to fire or excessive heat.
- Never try to disassemble or repair the charger or this light. Electric shock may result. Contact us for warranty and repairs.
- Never alter the plug on your charger. If the plug will not fit into the available outlet, have a proper outlet installed by a qualified electrician. Trying to plug into an improper outlet can result in shock.
- Any battery may leak harmful chemicals which may damage skin, clothing, or the inside of the light. To avoid risk of injury, do not let any material leaked from a battery come in contact with eyes or skin. In the event of skin contact, wash the affected area immediately and obtain prompt medical attention.
- Never allow liquids to spill on the charger or the light and do not charge outdoors, as the unit is not waterproof. Exposure to rain or other liquid could result in fire or electric shock.
- Do not charge or operate the light near flammable materials.
- Do not charge battery in gas-tight enclosures as gas may be emitted under certain conditions and can explode if concentrated and confined.
- Do not operate the light while connected to the charger.
- Never connect the light to any item other than the supplied charger. Doing so may damage the product and void your warranty, and could possibly result in fire, electric shock or other bodily injury.
- Exposure of the light and accessories to excessively high temperatures above 122°F (50°C) can heat-damage plastic parts, electronic components and the batteries.
- Never store this light in temperatures below -4°F (-20°C). Doing so may damage the light's electronic components.
- Recharge the Battery at temperatures: 32°F to 122°F (0°C to 50°C) to avoid hazardous gas venting from the battery cells and potentially reduced battery capacity.
- Never use a charger with a damaged or worn power cord or plug. This could result in electric shock, burns or fire. Contact us to obtain a replacement.
- Unplug the charger from the wall and light before attempting any cleaning in order to avoid the risk of electric shock.

## PROTECTION OF CHILDREN:

- This product is not designed, intended or recommended for children.
- Never allow children to play with, or otherwise handle or operate, the light, its battery or charging apparatus, as injury to themselves or others could result.
- Keep all accessories and components out of the reach of small children. Small parts, in particular, might present a choking hazard to children.